
Carburetor basic settings

MIKUNI SOLEX PHH Type List



Carburetor basic settings

1 Fuel pressure adjustment (SOLEX,

WEBER) - Adjust the pressure of the fuel flowing from the fuel pump to the carburetor with a fuel regulator while watching the fuel pressure gauge. ÿ "Fuel pressure at idling"

4 cylinders...0.25 to 0.30kg/cm2 (0.0247 to 0.0294MPa) 6 cylinders...0.30 to

0.35kg/cm2 (0.0294 to 0.0343MPa) $\ddot{\rm y}$ "Fuel pressure at maximum RPM" It is

desirable for the fuel

pressure not to change even at high RPM. If the fuel pressure at

high RPM is 0.05kg/cm2 (0.049MPa) or more lower than the fuel pressure at idling, this may be due to insufficient discharge or poor piping, so a review is required.

② Oil Level Adjustment (SOLEX,

WEBER) - With the jet block removed, idle the engine for about 15 seconds and measure and adjust the amount (height) of gasoline in the carburetor with an oil level gauge.

ÿ "Oil level height"

| | | Street, Zeroyon | Mountain pass, | | | | | |
|--|------------------------|-----------------|-----------------|--|--|--|--|--|
| | •SOLEX 40ÿ44ÿ | 19-20mm | Circuit 21-22mm | | | | | |
| | •SOLEX 50ÿ | 20.5 to 21.5 mm | 22–23 mm | | | | | |
| | •WEBER 40, 45, 48, 50ÿ | 26-27mm | 28 to 30 mm | | | | | |

3 Jet settings reference

| igo rotorottoo | | | | | | | | |
|--|---|------------------------|----------------------------------|-----------------|-----------|----------|--|--|
| SOLEX44ÿ 6 cylinder | Outer Venturi Needle Valve Main Jet Air Jet Pilot Jet Pump Nozzle | | | | | | | |
| •2400cc | 34ÿ 36ÿ | 1.8 | #150ÿ170 | #200ÿ220 | #55ÿ57.5 | #40 | | |
| •2800cc | 38ÿ | 1.8 | #170ÿ190 | #220ÿ240 | #55ÿ57.5 | #40ÿ45 | | |
| •3000ÿ3100cc | 40ÿ | 2.0 | #180ÿ200 | #230ÿ250 | #57.5ÿ60 | #45ÿ50 | | |
| SOLEX44ÿ 4 cylinder | Outer Venturi N | eedle Valve Main Jet / | Air Jet Pilot Jet Pun | np Nozzle | | | | |
| •1600ÿ1800cc | 36ÿÿ40ÿ | 1.8 | #160ÿ190 | #210ÿ230 | #55ÿ57.5 | #40 | | |
| •2000ÿ2200cc | 38ÿÿ40ÿ | 1.8 | #180ÿ200 | #210ÿ230 | #55ÿ57.5 | #40ÿ45 | | |
| SOLEX50ÿ 6-cylinder outer venturi Needle valve Main jet Air jet Pilot jet Pump nozzle #40-45 | | | | | | | | |
| •3000ÿ3100cc 43ÿ | | 2.0 | | 00~230 #70~72.5 | | | | |
| SOLEX50ÿ 4 cylinder | Outer Venturi N | np Nozzle | | | | | | |
| •2000ÿ2200cc 43ÿ | | 1.8 | #200ÿ220 #160ÿ180 #62.5ÿ67.5 #40 | | | | | |
| WEBER 45ÿ 6-cylinder outer venturi needle valve main jet air jet slow jet pump nozzle | | | | | | | | |
| •2400cc | 36ÿ | 175 | #145ÿ165 | #210ÿ230 | 55F9/8/11 | #4.0 | | |
| •2800cc | 38ÿ | 200 | #165ÿ185 | #220ÿ240 | 55F9/8/11 | #4.0 | | |
| •3000ÿ3100cc | 40ÿ | 200 to 225 | #175ÿ195 | #220ÿ240 | 60F9/8/11 | #4.0ÿ4.5 | | |
| WEBER45ÿ 4 cylinder Outer Venturi Needle Valve Main Jet Air Jet Pilot Jet Pump Nozzle | | | | | | | | |
| •1600ÿ1800cc | 36ÿÿ40ÿ | 175 | #155ÿ175 | #210ÿ230 | 55F9/8/11 | #4.0 | | |
| •2000ÿ2200cc | 38ÿÿ40ÿ | 175ÿ200 | #175ÿ195 | #210ÿ230 | 55F9/8/11 | #4.0ÿ4.5 | | |
| | | | | | | | | |

Notes: - The above data is for reference only. It will vary depending on engine specifications, driving purpose, temperature, air pressure, etc. - Set the jet after completing fuel

pressure and oil level adjustments. - Changing the needle valve size will change the oil level.

You will need to adjust the oil level again. - Needle valves are consumables. If the oil level

becomes unstable, replace it with a new one. - Changing the outer venturi diameter will change the jet setting. Please set it again.

