

## S20 Tightening Torque Table (Nissan Service Data)

Note: The above information is for standard engines as described in Nissan's maintenance manual. The tightening torque may differ for tuned engines.

## S20 Engine Main Tightening Torque

## Nissan Service Data

Fastening points	Fastening torque (kg-m)
Cam Bracket Nut	1.4 - 1.8
Main bearing cap bolt	10.0-11.0
Same side bolt	5.0 - 6.0
Connecting rod bolt	5.0 - 5.5
Oil Pump Drive Gear Nut	3.2 - 4.3
Oil pan bolt	0.7 - 0.9
Crank Pulley Bolt	20.0 - 25.0
Cylinder Head Bolts	6.5 - 7.5
Cylinder Head Lower Nut	6.0 - 7.0
Chain Tensioner Bolt	1.5 - 2.4
Camshaft Sprocket Bolt	4.5 - 5.5
Rear end plate bolts	1.4 - 1.8
Flywheel Bolts	10.0 - 11.0
Clutch cover bolt	1.4 - 1.8
Oil pump idler gear groove nut (left hand thread)	12.0 - 14.0

## transmission

Fastening points	Fastening torque (kg-m)
Clutch housing mounting bolt	1.9 - 2.2
Reverse idler shaft nut	6.3 - 7.3
Reverse idler set screw	1.1 - 1.3
Rear extension mounting bolt	1.5 - 2.2
Check Ball Plug	1.1 - 1.3
Main shaft lock nut	30
Drain, Filler Plug	3.5 - 5.0
Reverse lamp switch	2.0 - 3.0