


SOLEX50ÿ exploded view and parts list



Parts Price List

Number	Part Number	Product Name	Quantity		Price (yen)
			required 4 cylinders 6	6	
	N101,354	Float chamber cover Assy Lever			-
1	N107,071	Assy Gasket	6	232 3 4 6 4	2,000
2	BD34/44	Plug	3	2 3 2 3 4 6 2 3 4 6 2	100
3 4	N101,325	screw Screw,	3	2 3 2 3 2 3 2 3 2	-
5	N101,176	throttle adjustment spring bracket,	3	2 3 2 3 2 3 1 2 1	350
6	4/148	throttle	1		170
7	N107,073	adjustment nut Washer Pin, float			1,650
8	BDC36/35				140
9	B42/75	bracket,			140
10	N101,047	starter spring			140
11	N101,213	Spring, starter return Pump plug			500
12	B30/61	Float Assy (Reproduction) Snap			500
13	N102,064	ring Bolt			200
14	N101,330	Terminal Pilot screw Washer			13,800
15	BSW28/69	Starter cover			140
16	B2=0508	Spring,			170
17	N102,060	starter disc,			-
18	N101,181	starter bolt, banjo Air			500
19	B34/83	funnel			100
20	N101,083	(L-50mm) Filter			-
21	N101,063	Assy Fuel pipe Assy			200
22	N101,008	(Straight) Same (T)			1,000
23	N101,316	Same (L)			-
24	N101,322				8,000
25	N101,092				450
26	N101,339				4,000
26-a	N107,131				4,000
26-b	N107,132				4,000
27	N101,080	Washer	4	6	140
28	N101,254	Spring, float pin Needle	4	6	200
29	N101,215	valve assembly	2	3	3,150
30	N100,432	Packing, needle valve Jet	2	3	450
31	N101,253	block assembly Plug	4	6	3,300
32	N101,315	screw Washer	2	3	-
33	BD34/88	Screw, jet	2	3	100
34	N101,033	chamber cover Pilot jet Packing, small	4	3	1,120
35	N101,043	venturi Washer	4	6	640
36	N101,019		4	6	200
37	BD34/87		8	12	70

Number	Part Number	Product Name	Quantity		Price (yen)
			required 4 cylinders 6	6	
38	W4-05	Spring washer Screw			70
39	N101,320	Gasket,			200
40	N101,328	float chamber cover Gasket, jet chamber	8	12 8 12 2 3	550
41	N101,018	cover Jet chamber cover			280
42	N101,005				1,320
43	B21/156	O-ring			80
44	N101,044	Pump weight			170
45	BN19/99	Ball			140
46	N101,310	Bolt			330
47	VM18/79	Spring washer Lever,			100
48	N101,342	connecting Pump rod			-
49	N102,220	Pump spring (Reprint)	2	3	900
50	N101,030	Split pin Washer	2	3	270
51	Y-1006	Screw	2	3	70
52	BV26/32	Nut	4	6	70
53	N101,034		8	12	240
54	N101,319		8	12	-
55	B34/159	(Reproduction) Washer Large venturi	8	12	200
56	N101,303	46y) Small venturi (0.4 0.5 0.55)	4	6	5,500
57	N101,300	Screw Spring Diaphragm assembly	4	6	3,300
58	SW3-0416	Cover	4	6	170
59	N101,056	assembly	2	3	170
60	N107,030	Main jet Bracket	2	3	2,310
61	N101,067	assembly	2	3	-
62	N100,604	Screw Spring	4	6	640
63	N101,214	washer Screw			-
64	N107,026	Body	1	1	200
65	W4-04	assembly Gasket,	4	6 12	100
66	N101,324	pump body	8	12	-
67	N101,229	Seal, throttle	8	3	-
68	N101,016	shaft Collar (Reproduction)	2	3	200
69	BCD36/325	Pilot air jet Gasket, pump	2	12	200
70	N107,106	cover Washer Spring	8	3	360
71	B42/55	Repair kit (for 1 unit) Side	2	9	640
72	N107,048	lever kit (2.5.6.7.64.74)	6	7	200
73	M10/56		2	12	70
74	N107,112		8	3	660
75	N199,500-1A		2	3	4,230
76	15D114		22	3	5,230